

地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road,1875-3 Suzhou,china 传真/Fax: +86(512)-65975022 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 邮箱/E-mail: sales@syimotor.com

CMT03P Technical Instruction (English Version)



Product Name: Mid Motor Drive Unit

Product Model: CMT03P (Standard Configuration)

JGY 盛亿电机 imotor.com

苏州盛亿电机有限公司 Suzhou Shengyi Motor Co., ltd

地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road, 1875-3 Suzhou, china 传真/Fax: +86(512)-65975022 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 邮箱/E-mail: sales@svimotor.com

Important Notice

• Please read this manual and the attached installation manual carefully. If you are not clear about any part of the information in this manual, please do not install it. Please consult the sales office.

•Please contact the dealer for product information not described in this manual.

• Do not disassemble or modify the product except the information stated in this user manual.

• Distributors must abide by the relevant laws and regulations of their countries and regions.

•Please follow the instructions given in the manual to install this product and use it correctly.

• Loose, damaged and improper adjustment of bolts and nuts may lead to sudden fall and serious injury.

•Be sure to let users know the following:

Before riding, please check whether the wheels are fixed. When riding, don't be distracted by the instrument and fall off.

• Please be fully familiar with how to start the electric bicycle before riding it. Otherwise, it may accidentally start the electric bicycle and cause an accident. When riding at night, please make sure to turn on the headlights.

• Please unplug the battery before wiring or installing parts of the bicycle to prevent possible electric shock.

• Please use this product according to the instructions. Do not let people and children who have no operating experience, physical, sensory or mental diseases use this product, and do not let children play around this product.

• Please consult the dealer for information about product installation and adjustment software update (do not modify the software system without permission, which may easily lead to system failure). If there is any malfunction or problem, please consult the nearest dealer.

• This product is designed to be waterproof and can be driven in rainy days, but do not soak it in water, and do not use high-pressure water gun to clean it. As a result, the water immersion will lead to failure or rust.

•Please use this product with care, and do not apply strong impact.

• If you have any questions about the maintenance and use of the product, please consult the dealer at the place of purchase.

•Normal use of this product will cause natural wear and aging.



地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road,1875-3 Suzhou,china 传真/Fax: +86(512)-65975022 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 邮箱/E-mail: sales@syimotor.com

Catalogue

- 1. Mid motor
- 2. Attachment
- 3. Assembly method
- 4. Matters needing attention and fault analysis
- 5. Packing list
- 6. Packaging method



地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road, 1875-3 Suzhou, china 传真/Fax: +86(512)-65975022 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 邮箱/E-mail: sales@syimotor.com

1. Mid motor drive unit



 \star It can meet the needs of bicycle installation and is convenient to install;

The central drive unit has a high degree of modular design, which is ★ convenient for motor maintenance;

 \star The middle drive unit adopts half-package design, which is convenient for customers to customize;

- \star The center drive unit has double clutches;
- \star The center drive unit is controlled by torque and has a built-in controller;
- \star Large starting torque is more conducive to climbing;
- \star High efficiency, low power consumption and long cruising range.

1.1 Material and waterproof grade

Shell materials and surface treatment

Internal aluminum shell: die-cast aluminum surface is coated by electrophoresis with matt black;

Outer plastic shell: the surface of the plastic shell is sprayed with matt black and silver paint.

Protection grade: IP65; ;

Environment: temperature:-20 °C ~ 55 °C atmospheric pressure: altitude ≤ 1000 m.

Relative humidity: $\leq 90\%$ at 25 °C



地址: 江苏省苏州市通达路1875–3号 Address:Tongda Road,1875–3 Suzhou,china 总机/Tel: +86(512)–65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 传真/Fax: +86(512)-65975022 邮箱/E-mail: sales@syimotor.com

1.2 Main technical parameters

Model	CMT03P36	CMT03P48			
Rated power	350W@105RPM	450W@105RPM			
Maximum input power	500W(T<7min); max: 640W	650W(T<7min); max: 860W			
Rated voltage	36V	48V			
Maximum current limit	18A	18A			
Maximum torque	120Nm@25RPM	120Nm@25RPM			
Maximum speed	115RPM	115RPM			
Maximum efficiency	≥80%	≥80%			

2. Attachment


2.1 Instrument

2.1.1 Instrument name

Medium color TFT LCD instrument, model: APT 850C

LCD display description and key function description

Liquid crystal full display diagram:



Key function:



Up On/Off Down

苏州盛亿电机有限公司 Suzhou Shengyi Motor Co., Itd

地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road,1875-3 Suzhou,china 传真/Fax: +86(512)-65975022 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 邮箱/E-mail: sales@syimotor.com

2.1.2 Parameter setting

See 850C-ENS product specification -J-202106 billion.

2.2 Speed sensor

2.2.1 Product model

Model: SPL-10

2.2.2 Appearance



(speed sensor)



(M5 PH screw)



(cover)




(Induction magnet)

2.2.3 Product installation drawing



地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road,1875-3 Suzhou,china 传真/Fax: +86(512)-65975022 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 邮箱/E-mail: sales@syimotor.com



Locking Torque (<1Nm)

2.2.4 Specific specifications

Parameter	Numerical value
Rated voltage	DC5V
Rated current	5mA
Pulse/cycle	one
Installation distance	3-10mm
Working temperature	-30~70°C
Waterproof grade	IPX7
Authentication	CE ROHS

2.3 Dental tray

2.3.1 Appearance of dental tray: (as shown in the figure)



2.3.2 Tooth plate model: 42T unilateral chain cover

2.3.3 Basic parameters of dental tray

Number of teeth: 42 teeth Shape: concave, with circular pattern Color: black



地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road,1875-3 Suzhou,china 传真/Fax: +86(512)-65975022 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 邮箱/E-mail: sales@syimotor.com

2.4 Crank

2.4.1 Appearance of crank: (as shown in the figure)



2.4.2 Crank model: TS1-170AA

2.4.3 Basic parameters of crank:

Length: 170mm Material: 6061 Color: black

* Note: The left and right cranks have different thread directions, and the left crank is marked with "L" The right crank is marked with "R"

2.5 Other accessories



Connection Plate



Hex Torx sunk socket M6X65



Hex Torx sunk screw M6X18



Plastic shell (a set of 4)



hexagon socket pattern pan head screws M4X8





地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road,1875-3 Suzhou,china 传真/Fax: +86(512)-65975022 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 邮箱/E-mail: sales@syimotor.com



Chain Wheel nut M26 (reverse tooth)



Front light connection cable



Crank screw M8X20



Display connection cable



External speed senor connection cable



Rear light connection cable



Power connection cable

3. Assembly method


3.1 System schematic diagram and wiring diagram



地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road,1875-3 Suzhou,china 传真/Fax: +86(512)-65975022 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 邮箱/E-mail: sales@syimotor.com

3.1.1 System schematic diagram



「日日へ」の日に盛てした。


s y

imotor.com

苏州盛亿电机有限公司 Suzhou Shengyi Motor Co., Itd

地址: 江苏省苏州市通达路1875–3号 Address:Tongda Road,1875–3 Suzhou,china 总机/Tel: +86(512)–65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 传真/Fax: +86(512)-65975022 邮箱/E-mail: sales@syimotor.com





地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road,1875-3 Suzhou,china 传真/Fax: +86(512)-65975022 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 邮箱/E-mail: sales@syimotor.com

3.2 Schematic diagram of loading

3.2.1 Threading

Penetrating the external speed sensing adapter, headlight adapter, instrument adapter, rear light adapter and power adapter into the whole vehicle according to the requirements of the whole vehicle;

Insert the above wires into the motor according to 3.1.2 System Wiring Diagram; Arrange the line length and position;



3.2.2 Install the motor

Insert three hexagon socket countersunk screws M6X65 and three hexagon socket countersunk screws M6*18 into the three holes of the frame connecting plate as shown in the figure and lock them(locking torque: 8-10Nm);





地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road,1875-3 Suzhou,china 传真/Fax: +86(512)-65975022 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 邮箱/E-mail: sales@syimotor.com

3.2.3 Install the plastic housing.

Fix the plastic shell to the motor;

Lock six M4X8 hexagon socket head screws as shown in the figure(locking torque: <1Nm);











3.2.4 Install the tooth plate and lock the screw of the tooth plate.

Install the tooth disk assembly on the motor according to the spline groove direction;

Tighten the nut (anti-tooth) of the tooth plate in the reverse direction(locking torque: 20-24Nm);



苏州盛亿电机有限公司 Suzhou Shengyi Motor Co., Itd

地址: 江苏省苏州市通达路1875–3号 Address:Tongda Road,1875–3 Suzhou,china 总机/Tel: +86(512)–65963935 / 65977525

3.2.5 Install left and right cranks and lock crank screws.

Sleeve the crank on the central shaft (the included angle between the left and right cranks is 180)(locking torque 30-35Nm);


Lock the crank screw as shown in the figure;





3.2.6 Install external speed sensor and magnetic steel.

See 2.2.3 Product Installation Diagram for installation requirements.



JGHI 盛亿电机

苏州盛亿电机有限公司 Suzhou Shengyi Motor Co., Itd

地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road, 1875-3 Suzhou, china 传真/Fax: +86(512)-65975022 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 邮箱/E-mail: sales@syimotor.com

4. Matters needing attention and fault analysis

motor.com

4.1 Matters needing attention

It should be parked in a ventilated and dry warehouse. It should not be parked in a damp, acid and alkali place, nor should it coexist with magnetic articles.

Each connector is plugged into place according to the arrow;

Liquid crystal avoids the impact of sharp objects;

It is recommended that the product should not be overloaded for a long time.

Products should avoid wading or soaking in water.

serial num Fault phenomenon Possible causes of failure debugging ber The motor cannot be Welding deformation of frame Reduce welding deformation one mounted on the frame. connecting plate of frame. Plug-in is not connected Check all plug-ins and connect properly. 2 Meter no display Use non-standard instruments. Use our standard instrument. The battery runs out. Charge as required The external speed sensor plug-in is not connected Check plug-in and connect Meter kilometers are not three properly. displayed. Magnetic steel is not installed Check the position of magnetic steel and install it. in place. Unreasonable magnetic steel Adjust the position distance of Meter kilometer display is position distance magnetic steel. four abnormal. There is strong environmental Change the environment interference The light control module is not Install the light control module installed. Plug-in is not connected The front/rear lights are five Check all plug-ins and connect off. properly. The rated voltage of front/rear Replace the front/rear lights lamps does not match. with the correct voltage. No response when the Plug-in is not connected Check all plug-ins and connect six brake is cut off. properly.

4.2 General fault analysis



地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road,1875-3 Suzhou,china 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 传真/Fax: +86(512)-65975022 邮箱/E-mail: sales@syimotor.com

Note: When the motor works without external force, it is normal for the crank to follow.

Wrong definition error NO **LED** flashing describe code Flash once per second 1 0x00 normal --2 0x10 overtension Flash once restorability 3 0x11 undervoltage Flash twice restorability Motor speed 4 0x12 feedback failure (such Flash 4 times restorability as motor stalling) Overtemperatu 5 0x13 Flash 9 times restorability re beyond 6 0x14 Voltage fault Flash 10 times retrieve beyond 7 0x15 Abnormal output Flash 11 times retrieve beyond 8 0x16 MCU fault Flash 12 times retrieve Flying car beyond 9 Flash 13 times 0x17 retrieve protection beyond 10 0x18 Pedal sensor failure Flash 14 times retrieve beyond Speed sensor 11 0x19 Flash 15 times failure retrieve The controller can't communicate with the Communication 12 0x30 instrument, failure and the instrument sends a fault code. Flash 3 times restorability overflowing 13 0x21 overflowing MOS tube beyond Flash 6 times failure retrieve the voltage Turn 14 0x22 Flash 8 times restorability too high

4.3 Other fault analysis and error codes



地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road, 1875-3 Suzhou, china 传真/Fax: +86(512)-65975022 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 邮箱/E-mail: sales@svimotor.com

NO	error code	Wrong definition	LED flashing	describe
15	0x23	Phase line fault	Flash 7 times	beyond retrieve
16	0x24	Hall fault	Flash 5 times	restorability
17	0x25	Brake failure		restorability

note:

Recoverable-after the alarm, the EPAC drive system will detect it in real time. After the fault disappears, the alarm will be relieved and normal operation will be achieved.

Unrecoverable-epac drive system can't work normally. Turn off the power and troubleshoot.

The display instrument can display error codes or error messages.

5. Packing list

- 1. 1 central drive unit
- 2.1 instrument
- 3. 1 set of speed sensor (including magnetic steel)
- 4. 1 set of dental tray assembly
- 5. Left crank 1PCS
- 6. Right crank 1PCS
- 7. 1 set of plastic shell
- 8. Tooth disk nut M26 (anti-tooth) 1PCS
- 9. Crank screw M8X20 (used to install crank) 2PCS

10. Hexagon socket pattern pan head screw M4X8 (used to install plastic shell) 6PCS

1. Hexagon socket type countersunk head screw M6X65 (used to connect the motor and the frame connecting plate) 3PCS

12. Hexagon socket countersunk head screw M6X18 (used to connect motor and frame connecting plate) 3PCS

- 13. One external speed sensing adapter.
- 14. 1 headlamp adapter
- 15. 1 instrument adapter cable
- 16. 1 connector for rear light



17. 1 power adapter cable

苏州盛亿电机有限公司 Suzhou Shengyi Motor Co., Itd

地址: 江苏省苏州市通达路1875-3号 Address:Tongda Road, 1875-3 Suzhou, china 传真/Fax: +86(512)-65975022 总机/Tel: +86(512)-65963935 / 65977525

直线/Tel: +86(512)-65963936 / 65974850 邮箱/E-mail: sales@syimotor.com

6. Packaging method

Wrap the motors in plastic film bags, and put 3 sets in one box;

Accessories are packaged separately from the motor; (Pay attention to counting quantity);

* In addition, the connecting frame is shipped separately in advance, which is convenient for welding the frame in advance and facilitating production arrangement.